



STR Tubeless Ready Tape Instructions

1. Clean and degrease the rim bed.
1(B) Mulefut rims only: Install a SUNringle nylon rim strip before applying the tubeless tape
2. Start applying the tape at the rim seam opposite of the valve hole.
3. Apply the tape under tension in the rim bed. Ensure that the rim tape is applied centered in the rim bed.
4. Overlap the tape for about 50-75 mm and cut it.
5. Push the tape into the rim bed

STR Tubeless Ready Valve Instructions

1. Locate the position of the valve hole.
2. Put a hole the size of the tubeless valve into the tape from the tire side of the rim.
3. Remove valve cap and nut.
4. Insert valve through rim.
5. Thread nut onto valve.
6. Tighten the nut by hand tight without using any tools.



For more info visit:
www.sun-ringle.com/support



WWW.HAYESCOMPONENTS.COM

PN 47-32307

STR Tubeless Ready Sealant Instructions

1. Follow the STR tubeless tape and valve instructions.
2. Install the first tire bead onto the rim.
3. Install the second tire bead.
4. Hang the wheel with valve located at the 12 o'clock position and inflate the tire. Never exceed 40psi.
5. Check to make sure both beads are seated on the rim completely
6. Deflate the tire and remove the valve core from the valve stem.
7. Shake the 2 ounce bottle of STR tubeless sealant well and add to the tire through the valve.
8. Inflate tire to desired pressure. DO NOT exceed max pressure rating on the rim (if applicable).
9. Holding the wheel vertically, shake the tire towards and away from your body to direct the sealant up the tire sidewalls. Rotate the tire and repeat the shaking product until there are no visible leaks. Lay the wheel flat, check for leaks and repeat as necessary.