



Jumping Flea Front Hub



Picture #	Part #	Description
2	EJFFAXK	Axle kit (inner SUB axle)
4	EJFFCAPL	End cap (drive side)
5	EJFFCAPR	End cap (non-dirve side)
5	EH0912T-10	Bearing kit (#6804) 10-Pack
5	EH0912T	Bearing (#6804)

Jumping Flea Rear Hub



Picture #	Part #	Description
6	EHL955T	Cog carrier Alloy (w/pawls - spings)
7+8	EJPAWL	Pawl & Spring kit
3	EJFRCAPK	End cap kit (non-drive, 12mm axle spacer)
4	EJFRCAPKTH	End cap kit (drive, 12mm threaded)
18+19	EJ008	Hub Bearing kit w/crush tube/snap ring
18	EH0900T-10	Bearing kit (#6001) 10-Pack
18	EH0900	Bearing (#6001)
19	EH0901T-10	Bearing kit (#6902) 10-Pack
19	EH0901T	Bearing (#6902)
2	EJFAXK135	Axle kit (135mm)
2	EJFAXK150	Axle kit (150mm)